



# DPVR AIO Upgrade Firmware Steps



1. Put **update.zip** from PC to device root





2. Turn on your AIO, find **"Upgrade/Update"** in your right side launcher and double click.




3. Find button on the **top right corner**, press **Local upgrade/update**, as below



4. Waiting for system backup and press **OK**, wait for update success.



5. Click **the middle symbol** to restart devcie



6. After restart, back to system upgrade, click back to factory settings then OK

